

Oncam C-Series

Conduit box drilling template instructions

*Please note that if wall-mounting, the inlet to the backbox should be facing directly up or directly down and the indicating arrow on the camera should be facing directly up. The housing and faceplate can be rotated 180° by removing the faceplate depending on your requirements. The Oncam logo on the camera should be above the dome.

The inlet must face up or down and cannot be mounted to the left or right.

1. Set up the drilling template at the final location. *Please see note above.
2. Pre-drill holes for screws based on the template.
3. Remove the faceplate from the backbox.
4. Screw the backbox into the pre-drilled holes.
5. Insert the ethernet cable through the inlet on the back or side of the backbox.
6. Re-attach the faceplate to the backbox.
7. Remove the camera's dome housing from the rear housing.
8. Pull cables into the rear housing through the cable gland and plug in.
9. Attach the rear outdoor housing to the backbox faceplate with the housing red arrow facing upwards.
10. Install the camera.
11. Re-attach the outdoor dome housing.

For further instructions on installing the C-Series Outdoor Plus housing, please refer to the Quick Start Guide.